


Breakout


Installation

Simply copy the file Breakout.gme in the root directory of your Flash Card. The SP600 finds the game automatically on the card and shows the item "Breakout" in the menu "Game".

Main menu




Start a new game

Select "Start Game" in the menu or press .

View Highscore


Select "Highscore" in the menu.

Return to main-menu

Select "Exit" in the menu or press .

Gameplay






Turn your SP600 to play Breakout!



Goal of the game

Destroy as many bricks as possible.


Keys:

-  Move bar right
-  Move bar left
-  Start ball
-  Start ball
-  Pause/continue game

Menu "Pause"






Continue playing

Select "Resume" in the menu or press .


Play next audio track

Select "Play next track" in the menu.

Change audio volume

-  Select "Change Volume" in the menu→"Change Volume" appears inverted
-  Move the Jog-dial to change the volume.
-  Press the Jog-dial to return to the menu "Pause".

Quit game

Select "Quit Game" in the menu or press .

The actual score will be discarded.